


EV West - Curtis 1238/1239 Brake Transducer Schematic

Revision 1.6



Note: In programming the Curtis controller, confirm User Settings > Brake Type is set to 1 for transducer use.